

---

# Electrical Engineering Vocabulary

---

*Downloaded  
from  
[evoluir.abar.org.br](http://evoluir.abar.org.br)  
by Rhodes &  
Clarke*

---

## MASTERING THE LANGUAGE OF ELECTRONICS: YOUR ESSENTIAL GUIDE TO ELECTRICAL ENGINEERING VOCABULARY

---

Every field has its own unique language, a specialized set of terms that allow professionals to communicate complex ideas quickly and accurately. In the world of electricity and

electronics, this language is known as **electrical engineering vocabulary**. Whether you are a student just beginning your studies, a hobbyist building your first circuit, or a seasoned professional brushing up on fundamentals, a solid grasp of these terms is essential. Without this shared vocabulary, even a simple conversation about voltage drop or power factor can become confusing. This comprehensive guide will walk you through

the core terminology used daily in electrical engineering, helping you speak the language of electrons with confidence.

---

## FOUNDATIONAL CONCEPTS: THE CORE OF ELECTRICAL ENGINEERING VOCABULARY

---

Before diving into complex components, it is critical to understand the basic physical quantities that define electricity. These are the building blocks upon which all other terms rely.

# Voltage, Current,

# and Resistanc e

**Voltage**, measured in volts (V), is the electrical potential difference between two points. Think of it as the "pressure" that pushes electrons through a conductor. In a battery, the voltage tells you how much potential energy each electron can gain.

**Current**, measured in amperes (A), is the flow of electric charge. It represents the number of electrons passing a point per second. There are two main types: **direct current (DC)**, where electrons flow in one direction, and **alternating current**

(AC), where the flow reverses direction periodically.

**Resistance**, measured in ohms ( $\Omega$ ), is the opposition to current flow. A material with high resistance, like rubber, blocks current, while a material with low resistance, like copper, allows it to pass easily. The relationship between voltage, current, and resistance is defined by **Ohm's Law**, one of the most fundamental equations in electrical engineering:  $V = I \times R$ .

## Power and Energy

**Electrical power**, measured in watts (W), is the rate at which electrical energy is

transferred or converted. For DC circuits, power is simply the product of voltage and current ( $P = V \times I$ ). For AC circuits, the calculation becomes more complex due to phase differences between voltage and current.

**Energy**, measured in watt-hours (Wh) or joules (J), is the total amount of work done over time. When you pay your electricity bill, you are charged for the energy consumed, typically in kilowatt-hours (kWh). Understanding the difference between power and energy is a frequent topic in electrical engineering vocabulary.

---

**ESSENTIAL  
PASSIVE  
COMPONENTS**

---

Passive components do not require an external power source to operate and cannot amplify signals. They are the basic building blocks of circuits.

## Resistor, Capacitor , and Inductor

A **resistor** is a component that provides a specific resistance to current flow. It is used to limit current, divide voltages, and set biasing conditions in transistors. Resistors are color-coded to indicate their value.

A **capacitor** stores electrical energy temporarily in an electric field. It is

measured in farads (F), though most capacitors are in microfarads ( $\mu\text{F}$ ) or picofarads (pF). Capacitors are used for filtering, smoothing voltage, and timing circuits.

An **inductor** stores energy in a magnetic field when current flows through it. Measured in henries (H), inductors are key in transformers, filters, and power converters. They resist changes in current, creating the phenomenon of inductive reactance.

---

### ACTIVE COMPONENTS AND SEMICONDUCTOR DEVICES

---

Active components can control current flow and amplify signals. They are the heart of modern electronics.

# Diodes and Transistor S

A **diode** is a semiconductor device that allows current to flow in only one direction. This property is called **rectification**, and diodes are used to convert AC to DC. Variants include **Zener diodes** (for voltage regulation) and **LEDs** (light-emitting diodes).

A **transistor** is a three-terminal semiconductor device that can amplify or switch electronic signals. The two main types are **Bipolar Junction Transistors (BJTs)** and **Field-Effect Transistors**

**(FETs)**. Transistors are the fundamental building blocks of integrated circuits and microprocessors. Understanding terms like **base, collector, emitter** (for BJTs) or **gate, drain, source** (for FETs) is essential in electrical engineering vocabulary.

# Operation al Amplifiers and Integrate d Circuits

An **operational amplifier (op-amp)** is a high-gain voltage amplifier with

differential inputs. It is used in signal conditioning, filters, and mathematical operations like addition and integration.

**Integrated circuits (ICs)** are complex circuits of many transistors, resistors, and capacitors fabricated on a single piece of semiconductor material. They range from simple logic gates to powerful microcontrollers and memory chips.

---

## **CIRCUIT TOPOLOGY AND ANALYSIS**

---

How components are connected matters as much as the components themselves. This section covers key terminology for circuit configurations and analysis techniques.

# Series and Parallel Circuits

In a **series circuit**, components are connected end-to-end so that the same current flows through each one. The total resistance is the sum of individual resistances, and voltage divides across components.

In a **parallel circuit**, components are connected across the same two points, so the voltage across each is the same. The total resistance decreases, and current divides among the branches. Many real-world circuits use a

combination of both.

## Open, Short, and Ground

An **open circuit** is a break or interruption in the pathway, preventing current from flowing. A **short circuit** is an unintended low-resistance path that bypasses the normal load, often causing large currents and potential damage. **Ground** is a reference point in a circuit, often considered at zero voltage. Proper grounding is crucial for safety and signal integrity.

## Kirchhoff's Laws and Network Theorems

**Kirchhoff's Current Law (KCL)** states that the sum of currents entering a node equals the sum leaving. **Kirchhoff's Voltage Law (KVL)** states that the sum of voltages around a closed loop is zero. These laws are the foundation of circuit analysis.

Other useful theorems include **Thevenin's theorem** (replacing a complex circuit with a voltage source and series resistor) and **Norton's theorem** (replacing with a

current source and parallel resistor). These simplify analysis of networks.

---

## AC CIRCUITS AND COMPLEX IMPEDANCE

---

Alternating current brings additional complexity, requiring new vocabulary to describe phase relationships and frequency-dependent behavior.

# Frequency, Phase, and Reactance

**Frequency**, measured in hertz (Hz), is the number of cycles per

second of an AC signal. The standard power line frequency is 50 Hz or 60 Hz, depending on the country.

**Phase** describes the relative timing of two waves. A phase shift, measured in degrees or radians, occurs when voltage and current are not in sync due to reactive components.

**Reactance** is the opposition to current flow caused by capacitors (capacitive reactance) and inductors (inductive reactance). It varies with frequency. Combined with resistance, it forms **impedance**, denoted by  $Z$  and measured in ohms. Impedance accounts for both magnitude and phase.

# Power in AC Circuits: Real, Reactive, and Apparent

In AC circuits, power has three components. **Real power** ( $P$ , in watts) does actual work. **Reactive power** ( $Q$ , in volt-amperes reactive or VAR) oscillates between source and load without being consumed. **Apparent power** ( $S$ , in volt-amperes or VA) is the vector sum of real and reactive power. The

**power factor** ( $PF = P / S$ ) indicates how efficiently power is used. A low power factor can lead to higher currents and energy losses.

---

## ELECTRICAL MACHINES AND POWER SYSTEMS

---

From motors to generators, this vocabulary is essential for anyone working with high-power applications.

# Motors, Generators, and Transformers

An **electric motor** converts electrical

energy into mechanical motion. Types include DC motors, induction motors, and synchronous motors. Key parameters are torque, speed, and efficiency.

A **generator** does the opposite: it converts mechanical energy into electrical energy using electromagnetic induction.

A **transformer** transfers electrical energy between two circuits through mutual inductance. It can step up or step down voltage levels and is essential for power transmission. Terms like **primary winding**, **secondary winding**, **turns ratio**, and **core** are fundamental.

## Three-Phase Systems

Most industrial power distribution uses **three-phase AC**, where three voltage waveforms are offset by 120 degrees. This provides smoother power delivery and more efficient motors. Terminology includes **line voltage**, **phase voltage**, **delta connection**, and **wye (star) connection**.

## Protection and Safety

Key terms include **fuse** (a sacrificial device that melts to break a

circuit), **circuit breaker** (a resettable switch that trips on overload), **ground fault circuit interrupter (GFCI)** (protects against electric shock), and **surge protector** (diverts voltage spikes). Understanding these terms is critical for safe design and operation.

---

### ADVANCED TOPICS: SIGNAL PROCESSING AND COMMUNICATION

---

Modern electrical engineering extends into signals, data, and systems.

## Bandwidth h, Filters,

## and Noise

**Bandwidth** is the range of frequencies over which a device or system can operate effectively. **Filters** (low-pass, high-pass, band-pass, band-stop) selectively allow or block certain frequencies. **Noise** is any unwanted electrical disturbance that interferes with signals. The **signal-to-noise ratio (SNR)** quantifies the quality of a signal.

## Digital Logic and Microcont rollers

In digital systems, vocabulary includes

**Boolean algebra** (logic with true/false values), **gates** (AND, OR, NOT, etc.), **flip-flops** (memory elements), and **microcontrollers** (small computers on a chip). Terms like **clock frequency**, **instruction set**, **analog-to-digital converter (ADC)**, and **pulse-width modulation (PWM)** are commonplace.

---

## CONCLUSION

---

Mastering **electrical engineering vocabulary** is not just about memorizing definitions; it is about developing an intuitive understanding of how electrical systems behave. From the

simple resistor to the complex microcontroller, each term represents a concept that engineers use daily to create, analyze, and troubleshoot technology. Whether you are reading a circuit diagram, writing a specification, or discussing a design with colleagues, precise language ensures clarity and accuracy. This guide has covered the most essential terms, but the field is ever-evolving. Continue exploring, building, and learning—and your electrical engineering vocabulary will grow along with your expertise.