
How To Make A Wood Fired Pizza Oven

*How To Make A Wood
Fired Pizza Oven*

*Downloaded from
evoluir.abar.org.br by
Mcdowell & Justice*

THE ALLURE OF THE WOOD FIRED PIZZA OVEN

There is something deeply satisfying about a pizza cooked in a wood fired oven. The blistering heat, the smoky aroma, and the perfectly charred crust create an experience that a standard kitchen oven simply cannot replicate. Building your own wood fired pizza oven is not just a weekend project; it is an investment in countless future meals, gatherings, and memories. While the task may seem daunting, breaking the process down into clear, manageable stages makes it entirely achievable for a dedicated DIY enthusiast. This guide walks through the entire journey, from planning and material selection to the final curing fire, providing a comprehensive roadmap for how to make a wood fired pizza oven that will serve you for decades.

PHASE ONE: PLANNING YOUR OVEN DESIGN

Before you mix a single bag of mortar, you need a solid plan. The most common design for a home pizza oven is the Pompeii style, which features a true dome. This shape is not merely aesthetic; it efficiently reflects heat downwards onto the pizza floor and along the walls. The first major decision is the internal diameter of the cooking

floor. A standard size of 36 inches (about 90 cm) is excellent for most families, comfortably fitting a large pizza and a small fire on the side. A larger oven, say 42 inches, offers more cooking space but requires more materials and fuel to heat. A smaller oven around 30 inches heats up faster but limits your pizza size.

Your site selection is equally critical. Choose a location on level ground, away from overhanging trees or structures. Consider the prevailing wind direction, as you will want the oven mouth positioned so smoke does not blow back into your outdoor seating area. Also, think about convenience. You will be carrying pizza and food back and forth, so a location near your kitchen door or outdoor prep area is ideal. Check local building codes and homeowners' association rules before breaking ground, as some areas have restrictions on outdoor structures.

Selecting Materials: The Key to Longevity

The materials you choose directly determine how well your oven retains heat and how long it lasts. There is no room for compromise on the firebrick and refractory mortar. Standard red clay bricks will spall and crumble under the extreme temperatures of a wood fire.

You need **firebricks**, specifically those rated for continuous exposure to temperatures exceeding 2000°F (1093°C). These bricks are dense and heavy, designed to store and radiate heat efficiently.

For the mortar, use a **refractory cement** or a pre-mixed refractory mortar. Do not use standard Portland cement-based mortar for the oven chamber itself, as it will crack and fail. For the foundation and outer base, standard concrete and concrete block are perfectly acceptable, as these parts are far from the extreme heat. You will also need insulation. A high-temperature ceramic blanket insulation is standard for wrapping the dome before applying the final exterior finish. This insulation layer is what allows your oven to reach cooking temperature (800-900°F) in about an hour and hold that heat for hours of cooking.

PHASE TWO: BUILDING THE FOUNDATION AND BASE

Every great oven starts with an absolutely flat and stable foundation. The entire structure can weigh over a ton, so ground preparation is non-negotiable. Dig out a level area and pour a concrete slab that is at least 4 to 6 inches thick. Reinforce it with rebar or wire mesh for strength. The slab should extend at least a few inches beyond the footprint of your oven base on all sides. Allow this slab to cure for at least a week before building on top of it.

The base, or stand, elevates the oven to a comfortable working height, typically 36 to 42 inches off the ground. Build this using concrete blocks, filled with rebar and concrete for maximum stability. Lay the blocks in a running bond pattern, leaving a cavity in the center. This cavity

is immensely useful for storing firewood, keeping it dry and close at hand. On top of the block base, you need a leveling layer of concrete or a thick slab of stone. This surface must be perfectly level because it will support the oven floor. Finally, on top of this level base, you will place a layer of **calcium silicate board** or another rigid insulation. This prevents heat from the oven floor from dissipating into the concrete base below.

PHASE THREE: CONSTRUCTING THE OVEN FLOOR AND DOME

With the base complete, you can now lay the cooking floor. Start at the center and work outward, laying firebricks in a row. They should fit tightly together; a thin buttering of refractory mortar between the joints is all that is needed. Once the floor is complete, you will build a sand form to shape the dome. Damp play sand is piled into a dome shape on the oven floor. The sand form must be shaped carefully, as the bricks will follow its contour. Use a stick or a piece of string attached to the center point of the floor to ensure your sand dome is a true hemisphere.

Building the dome itself is the most rewarding step. You will cut your firebricks into tapered shapes to fit the curve of the dome. This is called "cutting the dovetail" and ensures the bricks lock together. Begin at the base of the dome, laying a first course of bricks around the perimeter of the floor. Each subsequent course is laid in a spiral, leaning inward toward the top of the sand form. At the very top, you will leave a small hole, which will later be covered by a "keystone" brick, the final brick that locks the entire arch together. Use refractory mortar sparingly on the brick faces that will touch the sand form. Do

not worry about the rough appearance of the interior; the inside of the dome will be smoothed out later if desired, but a rustic brick interior works perfectly.

The Oven Mouth and Flue

Before you complete the dome, you must frame the oven mouth. This is the opening through which you will feed wood and pizzas. It is typically an arch, tall enough to comfortably slide a pizza peel in and out. Build this arch using a wooden form and firebricks. Above the arch, you will create a flue opening where a chimney pipe will exit. The flue should be positioned to draw smoke efficiently over the top of the dome and out the chimney. A standard metal chimney pipe is then led from the flue opening to rise above the oven height, providing natural draft.

PHASE FOUR: INSULATION AND EXTERIOR FINISH

Once the mortar on the dome is fully cured (allow at least 48 to 72 hours), you will remove the sand from inside the oven through the mouth. This step is messy but incredibly satisfying. After the sand is removed, the next critical step is insulation. Wrap the entire dome with a high-temperature ceramic blanket. Use two layers for optimal heat retention. The insulation must be continuous, with no gaps that allow heat to escape. Overlap the edges of the blanket and use stainless steel wire or high-temperature tape to hold it in place. Cover the oven floor with a protective layer to keep debris off it.

The final exterior finish protects the insulation and gives your oven a

beautiful, finished look. The most traditional and popular finish is a stucco-like layer made from a mix of Portland cement, lime, sand, and water. Apply it in two or three coats, allowing each coat to dry before applying the next. You can color the final coat with integral pigment or paint it with a specialized masonry paint. This outer shell is also called the "housing" or "vermiculite dome." Some builders use a mixture of vermiculite and Portland cement for a lightweight, insulating outer layer. Whichever finish you choose, ensure it is weatherproof and durable.

PHASE FIVE: CURING YOUR OVEN

You cannot simply light a roaring fire and expect a perfect pizza. The refractory materials and mortar contain significant moisture, and heating them too quickly will cause cracking. The curing process is a slow, patient one. Start with a series of very small, cool fires over several days. On the first day, build a fire using only small twigs and a few pieces of kindling, letting it burn for about an hour before letting it die out naturally. Do not force the fire. The goal is to gently drive out moisture.

Day two: Build a slightly larger fire, but still keep it small. Let it burn for an hour or two. You may notice steam hissing from the dome and chimney. This is normal. Day three: Increase the fire size and duration, but still keep the temperature below 300°F for the first few hours of the burn. Gradually, over a period of five to seven days, you will work your way up to a fully roaring fire that brings the oven to pizza-cooking temperature. A properly cured oven will be dry, stable, and ready for its first pizza. This patience is rewarded with a structure that will last a lifetime.

PHASE SIX: COOKING TECHNIQUES AND WOOD MANAGEMENT

With your oven cured, you can now master the art of wood fired cooking. The key is managing your fire. Build a vigorous fire in the center of the oven floor using seasoned hardwood. Oak, maple, ash, and beech are excellent choices. Avoid resinous softwoods like pine, which produce soot and unpleasant flavors. You need to heat the oven for about 45 to 60 minutes until the dome is clean and white (indicating it has reached about 800°F to 900°F). Once the oven is hot, push the fire to the side or to the back of the oven.

Now, you are ready to cook. Slide your pizza onto the hot floor using a wooden or metal peel. The intense heat will cook a Neapolitan-style pizza in about 60 to 90 seconds. You will need to rotate the pizza with the peel to ensure even cooking. As the fire dies down over the next hour, the oven temperature

gradually lowers, making it perfect for roasting vegetables, baking bread, or even slow-cooking a roast. The retained heat in the firebricks allows you to cook for hours after the fire has died down to coals.

CONCLUSION: A LIFETIME OF FIRES

Learning how to make a wood fired pizza oven is a journey that blends craftsmanship, patience, and passion. From the poured foundation to the final curing fire, each step is an investment in a unique culinary tool that brings people together. The process is demanding but deeply rewarding. When you pull that first perfectly blistered, smoky-scented pizza from your own hand-built oven, the weeks of work will dissolve into pure satisfaction. You will have created not just an oven, but a centerpiece for your home, a source of warmth, and a stage for countless memorable meals. The fire is now yours to tend. **Happy building and even happier eating.**